

ADAPTER REFERENCE

PART/MODEL #	DESCRIPTION	APPLICATION
 <p data-bbox="245 940 630 968">PetroClear® Part # .75N1-12</p>	<p data-bbox="758 554 1179 617">3/4" NPT Inlet/Outlet Ports 1-12 UNF 3/4" Flow (Cast Iron)</p>	<p data-bbox="1265 554 1479 789">40502/5/10/30 P 40510 A 40510 D 40510/30 W 40810/30 P-DV 40910/30 P 40910/30 W</p>
 <p data-bbox="237 1421 639 1449">PetroClear® Part # .75N1-12A</p>	<p data-bbox="758 1031 1200 1094">3/4" NPT Inlet/Outlet Ports 1-12 UNF 3/4" Flow (Aluminum)</p> <p data-bbox="758 1115 1081 1171"><i>PetroClear Aluminum Heads are epoxy impregnated.</i></p>	<p data-bbox="1265 1031 1479 1266">40502/5/10/30 P 40510 A 40510 D 40510/30 W 40810/30 P-DV 40910/30 P 40910/30 W</p>
 <p data-bbox="248 1900 628 1927">PetroClear® Part # .75B1-12</p>	<p data-bbox="758 1514 1200 1577">3/4" BSP Inlet/Outlet Ports 1-12 UNF 3/4" Flow (Aluminum)</p> <p data-bbox="758 1598 1081 1654"><i>PetroClear Aluminum Heads are epoxy impregnated.</i></p>	<p data-bbox="1265 1514 1479 1749">40502/5/10/30 P 40510 A 40510 D 40510/30 W 40810/30 P-DV 40910/30 P 40910/30 W</p>

NOTE: If you experience frequent filter changes, it is recommended that you have fuel samples analyzed to determine the source of contamination, such as water, dirt, rust, bacteria, phase separation, etc.

ADAPTER REFERENCE

PART/MODEL #	DESCRIPTION	APPLICATION
	<p>1" NPT Inlet/Outlet Ports 1-12 UNF 3/4" Flow (Cast Iron)</p>	<p>40502/5/10/30 P 40510 A 40510 D 40510/30 W 40810/30 P-DV 40910/30 P 40910/30 W</p>
<p>PetroClear® Part # 1.00N1-12</p>		
	<p>1" BSP Inlet/Outlet Ports 1-12 UNF 3/4" Flow (Aluminum) <i>PetroClear Aluminum Heads are epoxy impregnated.</i></p>	<p>40502/5/10/30 P 40510 A 40510 D 40510/30 W 40810/30 P-DV 40910/30 P 40910/30 W</p>
<p>PetroClear® Part # 1.00B1-12</p>		
	<p>1" NPT Inlet/Outlet Ports 1-12 UNF 3/4" Flow (Aluminum) <i>PetroClear Aluminum Heads are epoxy impregnated.</i></p>	<p>40502/10/30 P 40510 A 40510 D 40510/30 W 40810/30 P-DV 40910/30 P 40910/30 W</p>
<p>PetroClear® Part # 1.00N1-12A</p>		

NOTE: If you experience frequent filter changes, it is recommended that you have fuel samples analyzed to determine the source of contamination, such as water, dirt, rust, bacteria, phase separation, etc.

ADAPTER REFERENCE

PART/MODEL #	DESCRIPTION	APPLICATION
 <p>PetroClear® Part # 1.00N1 3/8-12</p>	<p>1" NPT Inlet/Outlet Ports 1.375-12 UNF 1" Flow (Cast Iron)</p>	<p>40510/30 PA 40510/30 WA 40810/30 PA-DV 40910/30 PA 40910/30 WA</p>
 <p>PetroClear® Part # .75N1.5-16AD</p>	<p>3/4" NPT Inlet/Outlet Ports 1.5-16 UNF 1" Flow (Aluminum) <i>PetroClear Aluminum Heads are epoxy impregnated.</i> (Fits AD filters only with a 3.70" diameter)</p>	<p>40502/5/10/30 P-AD 40510 A-AD 40510 D-AD 40510/30 W-AD 40910/30 P-AD 40910/30 W-AD</p>
 <p>PetroClear® Part # .75B1.5-16ADA</p>	<p>3/4" BSP Inlet/Outlet Ports 1.5-16 UNF 1" Flow (Aluminum) <i>PetroClear Aluminum Heads are epoxy impregnated.</i> (Fits AD filters only with a 3.70" diameter)</p>	<p>40502/5/10/30 P-AD 40510A-AD 40510D-AD 40510/30W-AD 40910/30P-AD 40910/30W-AD</p>

NOTE: If you experience frequent filter changes, it is recommended that you have fuel samples analyzed to determine the source of contamination, such as water, dirt, rust, bacteria, phase separation, etc.

ADAPTER REFERENCE

PART/MODEL #	DESCRIPTION	APPLICATION
	<p>1" NPT Inlet/Outlet Ports 1.5 –16 UNF 1" Flow (Aluminum)</p> <p><i>PetroClear Aluminum Heads are epoxy impregnated.</i></p> <p>(Fits AD filters only with a 3.70" diameter)</p> <p>*Will not fit 5" diameter filters</p>	<p>40502/5/10/30 P-AD 40510A-AD 40510D-AD 40510/30W-AD 40910/30P-AD 40910/30W-AD</p>
<p>PetroClear® Part # 1.0N1.5-16AD</p>		
	<p>1" BSD Inlet/Outlet Ports 1.5 –16 UNF 1" Flow (Aluminum)</p> <p><i>PetroClear Aluminum Heads are epoxy impregnated.</i></p> <p>(Fits AD filters only with a 3.70" diameter)</p> <p>*Will not fit 5" diameter filters</p>	<p>40502/5/10/30 P-AD 40510A-AD 40510D-AD 40510/30W-AD 40910/30P-AD 40910/30W-AD</p>
<p>PetroClear® Part # 1.0B1.5-16ADA</p>		
	<p>1" NPT Inlet/Outlet Ports 1.5-16 UNF 1" Flow (Aluminum)</p> <p><i>PetroClear Aluminum Heads are epoxy impregnated.</i></p>	<p>50710P 50710W 51110/30P 51110/30W 51110A</p>
<p>PetroClear® Part # 1.00N1.5-16</p>		



NOTE: If you experience frequent filter changes, it is recommended that you have fuel samples analyzed to determine the source of contamination, such as water, dirt, rust, bacteria, phase separation, etc.

ADAPTER REFERENCE

PART/MODEL #	DESCRIPTION	APPLICATION
	<p>1-1/2" NPT Inlet/Outlet Ports 1.5-16 UNF 1" Flow (Aluminum)</p> <p><i>PetroClear Aluminum Heads are epoxy impregnated.</i></p>	<p>50710 P 50710 W 51110/30 P 51110/30 W 51110A</p>
<p>PetroClear® Part # 1.50N1.5-16</p>		
	<p>2" NPT Inlet/Outlet Ports Bolt Flange Inlet/Outlet Ports 1.5 –16 UNF 1" Flow (Aluminum)</p> <p><i>PetroClear Aluminum Heads are epoxy impregnated.</i></p>	<p>50710P 50710W 51110/30P 51110/30W 51110A</p>
<p>PetroClear® Part # D2.0N1.5-16</p>		
	<p>1" BSP Inlet/Outlet Ports 1.5-16 UNF 1" Flow (Aluminum)</p> <p><i>PetroClear Aluminum Heads are epoxy impregnated.</i></p>	<p>50710 P 50710 W 51110/30 P 51110/30 W 51110A</p>
<p>PetroClear® Part # 1.00B1.5-16</p>		



NOTE: If you experience frequent filter changes, it is recommended that you have fuel samples analyzed to determine the source of contamination, such as water, dirt, rust, bacteria, phase separation, etc.

ADAPTER REFERENCE

PART/MODEL #	DESCRIPTION	APPLICATION
 <p>PetroClear® Part # TC1-12</p>	<p>Test Cap for 1-12 UNF Filters 3/4" Flow</p> <ul style="list-style-type: none"> ■ Interior Epoxy Coating. ■ UL recognized for Ethanol blended fuels. ■ Designed for use with gasoline and diesel including Ethanol blended gasoline to E85, Biodiesel and ULSD (Ultra Low Sulfur Diesel). 	<p>Use in place of these filters: 40502/5/10/30 P 40510 A 40510 D 40510/30 W 40810/30 P-DV 40910/30 P 40910/30 W</p>
<p>PetroClear® Part # TC1-12</p>	<p>PetroClear® FILTERS ARE NOT TO BE USED IN AVIATION FUEL APPLICATIONS.</p>	
 <p>PetroClear® Part # TC1.5-16 AD</p>	<p>Test Cap for 1.5-16 UNF Filters 1" Flow</p> <ul style="list-style-type: none"> ■ Interior Epoxy Coating. ■ UL recognized for Ethanol blended fuels. ■ Designed for use with gasoline and diesel including Ethanol blended gasoline to E85, Biodiesel and ULSD (Ultra Low Sulfur Diesel). 	<p>Use in place of these filters: 40502/5/10/30 P-AD 40510 A-AD 40510 D-AD 40510/30 W-AD 40910/30 P-AD 40910/30 W-AD</p>
<p>PetroClear® Part # TC1.5-16 AD</p>	<p>PetroClear® FILTERS ARE NOT TO BE USED IN AVIATION FUEL APPLICATIONS.</p>	

NOTE: If you experience frequent filter changes, it is recommended that you have fuel samples analyzed to determine the source of contamination, such as water, dirt, rust, bacteria, phase separation, etc.

ADAPTER REFERENCE

PART/MODEL #	DESCRIPTION
	<p>PetroClear® Tank Vent 2" Fill Cap Base fits a standard 2" NPT threaded hole.</p>
<p>PetroClear® Part # TV-2</p>	<p>PetroClear® FILTERS ARE NOT TO BE USED IN AVIATION FUEL APPLICATIONS.</p>
	<p>PetroClear® Tank Vent 2" (Replacement Cap)</p>
<p>PetroClear® Part # TV-RC-2</p>	<p>PetroClear® FILTERS ARE NOT TO BE USED IN AVIATION FUEL APPLICATIONS.</p>

NOTE: If you experience frequent filter changes, it is recommended that you have fuel samples analyzed to determine the source of contamination, such as water, dirt, rust, bacteria, phase separation, etc.