

1 – Introduction

This manual contains parts information for Gilbarco® The Advantage® Series pumps and dispensers. Use this manual to identify part names, part numbers, and quantities required in a specific assembly.

How to Use This Manual

This manual provides detailed illustrations for The Advantage Series pumps and dispensers. Match the callout numbers from an illustration to the corresponding table to find information on a part name, part number, and quantity required for that assembly.

Parts Tables

The tables in this manual are set up as follows.

| Item # | Part Description | Current Part | Previous Part | Quantity |
|--------|------------------|--------------|---------------|----------|
| 1 | Lifting Bracket | N23295 | - | 4 |

Definitions for each column are provided below:

Item

The Item # column provides the digits that match the callouts on the related illustrations.

Part Description

The Part Description column provides a detailed name for each part from the illustration. information such as colors, dimensions, or other details are provided, wherever applicable.

Current Part

The Current Part column provides current Gilbarco part numbers for each item.

Previous Part

The Previous Part column provides the old Gilbarco part numbers that are no longer in use on current models. The previous part numbers are provided to help identify obsolete items that may still be in the field. Where possible, notes are provided to clarify the difference between old and new parts.

Note: When substituting an old part for new part.

Quantity

The Quantity column shows how many number of a particular part are used in that assembly.

Bulleted Items (Located Under Part Description)

These items are directly related to the previous part number listed. Parts are generally used for mounting or fastening hardware.

When Ordering Parts

Keep the following items in mind when ordering Gilbarco parts:

- 1 Furnish the required model number, date code, and original options. This information is stamped on a serial plate riveted to the center of the main frame base.
- 2 Provide the following information:
 - Part number
 - Quantity of the part required
 - Description of the part
 - Color, graphics, and other details required for order-entry items.

Note: An order-entry item is an item that can be ordered individually using its individual part number (not a part that comes only in a kit).

Related Documents

| Document Number | Description | GOLD SM Library |
|-----------------|---|--|
| MDE-2633 | Speaker Kits K35492 and K93846 For The Advantage Series | Advantage and Legacy [®] Models |
| MDE-2677 | Kits K35497 and K93757 Lighted Canopy Conduit For The Advantage Series | Advantage and Legacy Models |
| MDE-2742 | The Advantage Series Kit and Options Guide | Advantage and Legacy Models |
| PT-1736 | The Advantage/MPD [®] /CRIND [®] Card Reader Illustrated Parts Manual | Parts Manual |
| PT-1831 | VaporVac [®] Vacuum Assist Vapor Recovery Illustrated Parts Manual | Parts Manual |
| PT-1874 | CRIND Card Reader Illustrated Parts Manual Keypad Overlay Retrofit Configurations | Parts Manual |
| PT-1925 | The Advantage Series 4 X 4 Illustrated Parts Manual | Parts Manual |

Abbreviations and Acronyms

| Term | Description |
|--------|------------------------------------|
| ADA | Americans with Disabilities Act |
| ATC | Automatic Temperature Compensation |
| CRIND | Card Reader in Dispenser |
| E-CIM™ | Enhanced Customer Interface Module |
| EPP | Encrypting PIN Pad |
| GOLD | Gilbarco Online Documentation |
| J-box | Junction Box |
| LCD | Liquid Crystal Display |
| LED | Light Emitting Diode |
| MPD | Multi Product Dispenser |
| PCA | Printed Circuit Assembly |
| PCB | Printed Circuit Board |
| PIN | Personal Identification Number |
| POS | Point of Sale |
| PPP | Programmable Pump Preset |
| PPU | Price per Unit |
| STP | Submersible Turbine Pump |