4 – Cable Assemblies Section

AC Power Distribution (Conduit to Power Supplies)

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
02/91 to 10/95	Refer to "Main AC Harness" on page 4-4.	-	-
10/95 to Present			
Dual, Quad, and 6-hose MPD	T19612-G2	-	J404, J550, J551, J601, J708, P401
8-hose MPD	T19612-G2	-	J404, J550, J551, J601, J708, P401
Blender	T19612-G2	-	J404, J550, J551, J601, J708, P401

ATC

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
Pump Main Regulator to Pump, ATC, and VaporVac Controllers	R17995-G7	R17995-G6	J201, J301, J501, J1104
ATC Controller to Manager's Keypad	R19023-G2	-	J203, J901
Pump Controller Splitter	R19527-G1	-	J204, P204A, P802
Hydraulic Interface to VaporVac and ATC Controllers (see note)	R19665-G4	-	J105, J305, J1103
ATC Controller to Pump Controller	R19667-G1	-	-
ATC Controller to Conduit	R20128-G1	-	J307
ATC Controller to Pump Controller	R20146-G1	-	J203, J303
T-meter Box to	•		
Side A Probes	R20148-G1	-	J200, J202, PTP1, PTP2, PTP3, PTP4
Side B Probes	R20148-G2	-	J200, J202, PTP5, PTP6, PTP7, PTP8
IS Barrier to R20147-G1	R20150-G1	-	-
ATC Controller J101 Splitter	-		
Blenders (obsolete, see note 2)	-	T19483-G1	J101A, J101B, J306, P101A, P101B
Non-blender, 1-3 grade (obsolete, see note 2)	-	T19483-G2	J101A, J101B, J306, P101A, P101B
Non-blender, 4-grade (obsolete, see note 2)	-	T19483-G3	J101A, J101B, J104A, J104B, J306, P101A, P101B, P104A, P104B
ATC Controller to Main Displays	-		
06/90 to 08/96 (Spare Parts Item)	T17528-G1	-	J204, J801A/B
08/96 to Present	W03602-G1	-	J124A1, J124A2, J124B1, J124B2, J203, J204, J302A, J801A, J801B, J802A1, J802A2, J802B1, J802B2, J802C1, J802C2, J901, J911A, J911B, P302, P302A, P909

^{1.} Contact a Gilbarco representative before ordering part.

^{2.} No replacement.

Cable Assemblies Section Backlight Distribution

Backlight Distribution

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
Before 10/93	-	W02867-G2 (obsolete, see note 1) W02867-G1 (obsolete, see note 1)	J124A1, J124A2, J124B1, J124B2, J133A1, J133A2, J133B1, J133B2, P302, WT
10/93 to 10/96	-	W02867-G2 (obsolete, see note 1)	J124A1, J124A2, J124B1, J124B2, J133A1, J133A2, J133B1, J133B2, P302, WT
8/96 to Present	W03602-G1 (see note 2)	-	J124A1, J124A2, J124B1, J124B2, J203, J204, J302A, J801A, J801B, J802A1, J802A2, J802B1, J802B2, J802C1, J802C2, J901, J911A, J911B, P302, P302A, P909

Notes:

Beeper

Refer to "Pulser" on page 4-7.

Brand Panel Lighting

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
06/90 to 05/91	•		
Ballast to Side A Bezel	T19019-G1	-	P900A, WT
Ballast to Side B Bezel	T19019-G2	-	P900B, WT
(Bezel) (obsolete, see note)	-	W02478-G1	J900, XDS
02/91 to 08/92	<u> </u>	1	
(Bezel) (obsolete, see note)	-	T18690-G1	J900, J903A, J903B, J903C, J903D
(Bezel) (obsolete, see note)	-	T18690-G2	J900, J903A, J903B, J903C, J903D
04/92 to 07/93	<u> </u>	1	-
Ballast to Side A Bezel	T19019-G1	-	P900A, WT
Ballast to Side B Bezel	T19019-G2	-	P900B, WT
07/93 to Present	<u> </u>	1	
Ballast to Lamp Side A	T19019-G1	-	WT, XDS
Ballast to Lamp Side B	T19019-G2	-	WT, XDS
Note: No replacement.	l	1	1

^{1.} No replacement.

^{2.} Contact a Gilbarco representative before ordering part.

Call Button Cable Assemblies Section

Call Button

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks	
Conduit to Switch (production units only)	R20393-G1	-	A-A, B-B, P555	
Pump Controller to Bezels (retrofit kits only) (see note)	T18685-G1	-	J204, P141A, P141B, P204A	
Bezel to Switch (retrofit kits only) (see note)	R19542-G3	-	J141	
Note: Contact a Gilbarco representative before ordering part.				

Cash/Credit

Refer to "Grade Select (Cash/Credit)" on page 4-3.

Five-button Preset with Pump Stop (Membrane)

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
Five-button Preset (obsolete, see note)	-	T19355-G2	J202, P130A, P130B, P202A
Calibration Switch	R19527-G1	-	J204, P204A, P802
Pump Stop	T19336-G2	-	-
Note: No replacement.			

Grade Select (Cash/Credit)

Current Part	Previous Part	Associated Plugs and Jacks
/96)		
K94417-01	W02501-G3	-
K94417-01	W02501-G4	-
/96)	1	
K94417-01	-	J136A, J136B, J136C, J140
K94417-01	W02501-G2	-
K94417-01	W02501-G5	-
K94417-01	W02501-G6	-
K94417-01	W02501-G7	-
-	W03490-G2	G1A, G2A, G3A, G4A, G5A, G6A, G1B, G2B, G3B, G4B, G5B, G6B, J202, P1
	•	
T18549-G2	-	J139A, J202
	/96) K94417-01 K94417-01 /96) K94417-01 K94417-01 K94417-01 K94417-01	K94417-01 W02501-G3 K94417-01 W02501-G4 K94417-01 -

Cable Assemblies Section Main AC Harness

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
10/94 to Present	T18549-G2	-	J139A, J202
Pump Controller to Customer Interface			
06/96 to Present	R20311-G1	-	J202, J202A
Customer Interface to			
Main Access Door (06/90 to 05/93)	T17603-G1	-	J139, P140
Bezel (08/91 to 06/96)	T17696-G1	-	J139, P140A, P140B
Membrane Switch (06/96 to present)	T19731-G1	-	J136, J139
Soda Button Switch (06/96 to present)	T19731-G2	-	J139
Note: No replacement.		1	1

Main AC Harness

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
02/91 to 10/95			
48" MPD (except 4-grade), 36" Dual, 36" Quad, and Single-hose X + 0 (Spare Parts Item)	W02468-G4	W02468-G1	E1, J103, J305, J401, J502, J601,P550, P604, P920A, P920B, WT-1, WT-2, J103
36" and 48" Blender (Spare Parts Item)	W02468-G6	W02468-G3	E1, J305, J401, J502, J601, J701, J703, J704, J705, J708, P550, P920A, P920B, P923A, P923B, P924LA, P924LB

Main DC Harness

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks		
48" MPD (except 4-grade), 36" Dual,	48" MPD (except 4-grade), 36" Dual, 36" Quad, and Single-hose X + 0				
06/90 to 08/96 (obsolete, see note)	-	W02469-G4 W02469-G1	BUZZ, J101, J402, J407, J504, J911A, J911B, J921A, J921B		
08/96 to Present	W03601-G1	-	BUZZ, J101, J101J, J407, J504, J909, J921A1, J921A2, J921A3, J921B1, J921B2, J921B3, P402		
36" and 48" Blender					
08/96 to Present	W03601-G2	-	BUZZ, J101, J504, J909, J921A2, J921B2, J921HA, J921HB, J921LA, J921LB, P402		
Note: No replacement.	Note: No replacement.				

Main Display Backlight

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
06/90 to 08/96 (obsolete, see note)	-	T17550-G2	P113A, P133B, J802A. J802B, J802C
08/96 to Present	W03602-G1	-	J124A1, J124A2, J124B1, J124B2, J203, J204, J302A, J801A, J801B, J802A1, J802A2, J802B1, J802B2, J802C1, J802C2, J901, J911A, J911B, P302, P302A, P909
Note: No replacement.			

Main Display Data

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
Pump Controller to Displays, 06/90 to 08/96 (Spare Parts Item)	T17528-G1	-	J204, J801
Main Interface, 08/96 to Present	W03602-G1	-	J124A1, J124A2, J124B1, J124B2, J203, J204, J302A, J801A, J801B, J802A1, J802A2, J802B1, J802B2, J802C1, J802C2, J901, J911A, J911B, P302, P302A, P909

Main Regulator

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
Main Power Supply to Main Regulator (60 VAC)			
• 06/90 to 10/95	Refer to "Main AC Harness" on page 4-4.	-	-
• 10/95 to present (see note 1) (obsolete, see note 2)	-	R20210-G2	J502, J606
Main Regulator to Pump Controller			
• 06/90 to 03/96 (no options)	R17995-G7	R17995-G1	J201, J301, J501, J1104
• 04/94 to 01/96 (VaporVac)	R17995-G7	R17995-G2	J201, J301, J501, J1104
• 01/95 to 02/96 (ATC)	R17995-G7	R17995-G6	J201, J301, J501, J1104
01/96 to Present (VaporVac and ATC)	R17995-G7	R17995-G7	J201, J301, J501, J1104
Notes:			1

- 1. Contact a Gilbarco representative before ordering part.
- 2. No replacement.

Manager's Keypad

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
Pump Controller to Keypad			
• 06/90 to 09/91	R19023-G2	-	J901, J203
• 08/91 to 08/96	R19023-G2	-	J901, J203
Main Interface, 08/96 to Present	W03602-G1	-	J124A1, J124A2, J124B1, J124B2, J203, J204, J302A, J801A, J801B, J802A1, J802A2, J802B1, J802B2, J802C1, J802C2, J901, J911A, J911B, P302, P302A, P909

Cable Assemblies Section PPU Backlight

PPU Backlight

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
3-grade MPD			
06/90 to 04/91 (obsolete, see note 2)	-	T17557-G3 T17557-G1	P124A, P124B, J122A, J122B, J122C, J122D, J122E, J122F
05/91 to 08/96 (obsolete, see note 2)	-	T17557-G3	P124A, P124B, J122A, J122B, J122C, J122D, J122E, J122F
08/96 to Present	T19790-G3	-	J122A, P124
4-grade MPD			
• 10/91 to 08/96 (see note 1) (obsolete, see note 2)	-	T17557-G4	P124A, P124B, J122A, J122B, J122C, J122D, J122E, J122F, J122G, J122H
08/96 to Present	T19790-G1	-	J122A, P124
Blender		1	
08/91 to 08/96 (Spares) (see note 1) (obsolete, see note 2)	-	T17557-G5	P124, J122A, J122B, J122C, J122D, J122E, J122F
08/96 to Present	T19790-G1	-	J122A, P124
Dual and Quad		1	
08/96 to Present (see note 1)	T19790-G2	-	J122A, P124
Note: 1. Contact a Gilbarco representative before ordering pa	art	1	

PPU Data

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
06/90 to 08/96			
• 48", 3-grade, 06/90 to 08/96	T17536-G1	-	J121, J804
• 02/91 to 12/91	T17536-G1	-	J121, J804
Selectable Blender, 08/91 to 08/94	T17795-G1	-	J121, J804
48" Selectable Blender, 08/94 to 08/96	T17536-G6	-	J121, J804
36" Selectable Blender, 08/94 to 08/96	T17536-G7	-	J121, J804
08/96 to Present			
• 48", 3-grade	T19793-G3	-	J121, J804
• 48", 4-grade	T19793-G1	-	J121, J804
• 36", Dual/Quad	T19793-G2	-	J121, J804

PPP

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
PPP Controller to Keypad/Display	R19206-G1	-	J412, J413, J612
Pump Controller to PPP Controller			
• 03/91 to 10/91	R19281-G1	-	J102, J205, J411, P411A
• 04/91 to 10/91	R19281-G1	-	J102, J105, J205, J411
10/91 to Present	R19281-G1	-	J102, J105, J205, J411, P411A

^{2.} No replacement.

Pulser Cable Assemblies Section

Pulser

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
6/90 to 08/96	Refer to "Main DC Harness" on page 4-4.	-	-
08/96 to Present			
48" MPD (except 4-grade), 36" Dual, 36" Quad, and Single-hose X + 0	W03601-G1	-	BUZZ, J101, J101J, J407, J504, J909, J921A1, J921A2, J921A3, J921B1, J921B2, J921B3, P402
48" 4-grade MPD and Single-hose X + 1	W03601-G3	-	BUZZ, J101, J101J, J104, J504, J707, J909, J921A1, J921A2, J921A3, J921B1, J921B2, J921B3, P402
36" and 48" Blender	W03601-G2	-	BUZZ, J101, J504, J909, J921A2, J921B2, J921HA, J921HB, J921LA, J921LB, P402

Pump Controller to Hydraulic Interface

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
Pump Controller to Interface, 06/90 to 03/93	R19281-G1	R17996-G1	J102, J205, J411, P411A
PPP Support, 10/91 to Present	R19281-G1	R18945-G3 R18945-G2	J102, J205, J411, P411A

Pump Handle

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
Main DC Harness (06/90 to 08/96)	Refer to "Main DC Harness" on page 4-4.	-	-
Main Interface (08/96 to present)	W03602-G1	-	J124A1, J124A2, J124B1, J124B2, J203, J204, J302A, J801A, J801B, J802A1, J802A2, J802B1, J802B2, J802C1, J802C2, J901, J911A, J911B, P302, P302A, P909
Pump Handle (06/90 to 08/96)			
48" MPD (except 4-grade) and Blender 6-hose	W02477-G1	-	J913A, J913B, J913C, P911
• 48" 4-grade MPD	W02477-G2	-	J913A, J913B, J913C, J913D, P911
• 48" Single-hose X + 1 (10/91 to 07/94)	W02477-G2	-	J913A, J913B, J913C, J913D, P911
• 48" Single-hose X + 1 (07/94 to 08/96) (see note)	W02477-G7	W02477-G5	J913A1, J913A2, J913B1, J913B2, P911
48" Selectable Blender (see note)	W02477-G6	W02477-G4	J913A1, J913A2, J913B1, J913B2, P911
• 48" Single-hose X + 0 9 (see note)	W02477-G6	W02477-G3	J913A1, J913A2, J913B1, J913B2, P911
Pump Handle (08/96 to present)	N23730-G1	-	J913, P911

Cable Assemblies Section Pump Stop

Pump Stop

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks	
Pump Controller to Left Option Door	T18685-G1	-	J204, P141A, P141B, P204A	
Pump Stop Switch to T18685-G1				
• 09/92 to 12/96	R19542-G2	-	J141	
11/96 to Present	R19542-G2	-	J141	
Note: All parts may not be available as spare parts.				

Push-to-start Jumpers

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
MPD			
• 04/91 to 08/96	R15634-G79	-	J101
08/96 to Present	N23737-G1	-	P101J
Blender	N23169-G1	-	J411A-14, J411A-19

Two-wire Communications

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
Universal CRIND/Pump Two-wire Adaptor (01/91 to 10/95)	R19248-G1	-	P402B, P402C, P405
Pump Two-wire Adaptor (10/95 to 08/96)	R19248-G2	-	P402, P402B, P402C

Valve/STP

Cable Description	Current Part	Previous Part	Associated Plugs and Jacks
Main AC Harness (02/91 to 10/95)	Refer to "Main AC Harness" on page 4-4.	-	-
Coil Adaptor, 10/95 to Present	R19826-G3	-	P1, J2
Hydraulic Interface to Valves and Power Conduit (10/95 to Present)			
36" and 48" Blender (except 6-hose)	W03275-G1	-	J703, J704, J711, P403, P604, P710, P920A2, P920B2, P924HA, P924HB, P924LA, P924LB
6-hose Blender	W03275-G2	-	J703, J704, J705, J711, P403, P603, P710, P923A1, P923A2, P923A3, P923B1, P923B2, P923B3, P924HA, P924HB, P924LA, P924LB
48" MPD (except 4-grade), 36" Dual, 36" Quad, and Single-hose X + 0	W03275-G3	-	J103, P403, P604, P920A1, P920A2, P920A3, P920B1, P920B2, P920B3
48" 4-grade MPD and Single-hose X + 1	W03275-G4	-	J103, P403, P604, J709, P920A1, P920A2, P920A3, P920A4, P920B1, P920B2, P920B3, P920B4