

24 – Ultra-Hi Commercial Cables

Commercial Ultra-Hi Cables

Note: For cable block diagrams, refer to MDE-4334 Commercial and Retail Series Atlas Start-up/Service Manual.

Part Description	Current Part	Previous Part
AC Fuse Cable Assembly	M05110A001	-
Main AC Power Conduit and Wire Assembly - Pump	M05685A002	-
Main AC Power Conduit and Wire Assembly - Single Dispenser	M05684A002	-
Main AC Power Conduit and Wire Assembly - Dual Dispenser	M05686A002	-
Main AC Power Conduit and Wire Assembly (see note)	M05686A003	-
Assembly, AC Dual Conduit and Cable	M05692A002	-
Assembly, AC Dual Conduit and Cable (see note)	M05692A003	-
Display Cable, Single Side-load	C06455	-
Display Cable, Dual Side-load	M05109A001	-
Display Cable, Single Front-load	C06574	-
Backlight Power Cable - Side-load	M05108A001	-
Backlight Power Cable - Front-load	C06519	-
DC Conduit and Wire Assembly - Dispenser Mount TopKAT	M05683A002	-
DC Conduit and Wire Assembly - RS-485/Pulse-out	M05683A004	-
DC Conduit and Wire Assembly - Dispenser Mount TopKAT PLUS	M05683A006	
DC Power Cable	M05107A001	-
Handle Switch Cable, Single	M05105A002	-
Handle Switch Cable, Dual	M05105A001	-
Heater Cable 115 V	M05120A001	-
Heater Cable 230 V	M05120A002	-
Solenoid Cable and Terminal Block Assembly, Single	M04193A001	-
Solenoid Cable and Terminal Block Assembly, Dual	C06518	-
AC Combo Satellite Control Conduit and Wire - Pump	M07275A002	-
AC Combo Satellite Control Conduit and Wire - Dispenser	M07275A004	-
Totalizer ATC Sensor Cable	M05119A001	-
I.S. Barrier, Front-load	C06766	-
Not Shown		
Magnet, Actuator	Q12514-02	-
<i>Note: This part is for 9850KXTW1. Units built after August 2007.</i>		









