

Technical Service Bulletin

To: NeXGen Service and Help Desk Personnel

From: Allied Electronics Technical Support

Date: March 15, 2012

Re: Changing NeXGen Ethernet Settings

* For the remainder of this document, the NeXGen controller will be referred to as NXG.

The ANDI_DGS application allows NXG service and help desk personnel to modify NXG's Ethernet settings. This action may be performed via serial or Ethernet connection to NXG.

An assumption **MUST** be made that the individual performing the following procedure has acquired a basic understanding of **NXG** and the **ANDI_DGS** utility.

Note: If NXG is running PCI compliant software, an "Administrator" username and password <u>MUST</u> be setup in order to employ <u>ANY</u> ANDI_DGS functions (i.e. warm start, cold start, port assignment, port monitoring, Ethernet settings, etc).

The following is the procedure for changing NXG's Ethernet settings via *serial connection*:

- 1) Verify that a DB9 NXG POS connector (*Part #N9359-ADP*) is attached to the serial port on the PC running the ANDI_DGS application.
- 2) Verify that a straight-through CAT 5 cable is connecting the DB9 NXG POS connector to an available POS RS232 port on NXG.
- Launch ANDI_DGS and connect to NXG via the Serial option under *Communications Mode* on the *Connections* tab.

Fueling the Future of Service Station Automation

🖥 Allied Diagnostic							
File Trace Edit Help							
Connection Commu	inications	Commands	Status	Utilities			
Communications Mode Serial Ethernet Sign on Parameters Device Info DGS00 Services Supplied LOGRFA	Communic Port CON 960	cations Parameters Ethernet d Rate DataBits D V B V Connect	Serial	p Bits			

4) Once connected, click on the *Utilities* tab

5) From the *Utilities* tab, click CF Access under *Firmware Control.*

001111011				
🖥 Allied Diagnostic				
File Trace Edit Help				
Connection	Communications	Commands 🏻	Status	Utilities
Communications Serial Line C Ping Port Statistics COM1 Get Statist Reset	Related Control	Port Monitoring Configure Start Port Sniffer Display Start Stop	Firmware C Dow Re SRAM CF A	ontrol nload set Access ccess

6) Uncheck the *Use DHCP (default)* box and enter the IP information in the Ethernet Settings boxes.



- 7) Click *Apply Changes* and close out the **Compact Flash Configuration** box.
- Warm start NXG via the Reset button under *Firmware Control*. Refer to the technical service bulletin *ANDI_DGS Warm Start Procedures* for more information on this step.
- 9) Once NXG warm starts, the beep sequence should indicate the presence of an IP address and the information entered via ANDI_DGS.

The following is the procedure for changing NXG's Ethernet settings via *Ethernet connection*:

- 1) DHCP connectivity requires NXG to be connected via CAT 5 from the onboard Ethernet port to a LAN.
- 2) If the IP address has already been obtained via DHCP server, you are connected via Ethernet, and simply want to change the IP information, follow steps 4-9 above.
- 3) If the IP address has already been obtained (and known) and you are NOT able to make a serial connection
 - a) Run a crossover cable between NXG's onboard Ethernet port and the PC running the ANDI_DGS application.
 - b) Verify that the IP configuration of your PC falls within the range of NXG's IP configuration.
 - c) Launch ANDI_DGS and connect to NXG via the **Ethernet** option under *Communications Mode* on the *Connections* tab.

- d) Click Find Devices and the NXG's IP address should appear in the "Available Devices" box.
- e) Click **Connect** and follow steps 4-9 above.

🗄 Allied Diagnostic								
File Trace Edit Help								
Connection	Communications	Commands	Status	Utilities				
Communications M C Serial Ethernet Sign on Parameter: Device Info DGS00 Services Supplie LOGRFA	lode Communi s	cations Parameters Ethernet evice Name ort 527 Connect	Serial Available Devices < 10.0.8.47 Ping	? Find Devices				

Contact Allied Electronics Technical Support with any questions or concerns:

800-223-3619 SupportRequest@AlliedElectronics.com